n52te USFR MANUAL

Software Installation

- 1. Insert the n52te Installation CD into your PC's CD/DVD drive.
- The software should start automatically. If it does not, click the "Start" button and choose "Run". Click "Browse" and choose your CD drive. Select "setup.exe" and click "OK".
- 3. Follow the on-screen instructions to continue with the software installation.
- 4. After the installation is complete, select "Finish" and reboot when prompted.
- 5. After your PC boots up, connect the n52te to an available USB port on your computer.
- If you have Windows XP and you are prompted to allow "Unsigned Drivers", click "Yes" to proceed.
- If you have Windows Vista and you are prompted to verify the publisher of the driver, click "Install this driver anyway" to proceed.
- Once the drive have been initialized, please check to see if the installation was successful by proceeding to the next section of the manual titled "Installation Verification".

Installation Verification

- You will need to confirm that the installation was successful through the Device Manager.
- To get to Device Manager, right-click on "My Computer" and left-click on "Properties". Then left-click on "Hardware" and then on the "Device Manager" button.
- 3. Check to make sure that the Device Manager list includes:
 - a. A new entry under Human Interface Devices, "n52te".
 - b. A new entry under Human Interface Devices, "Virtual HID Device".

CONFIGURING n52te

n52te Editor

The n52te Editor is the tool used to customize and program custom functions to your n52te. Some examples of programmable functions are:

Single Key - Make a button on the controller work like a keyboard key.

Macros – Record a sequence of keyboard keystrokes, and/or mouse-button presses that can be saved and played back by the n52te at a later time.

Keymap Selector – Switch between the three color Keymaps (Blue, Green, Red) and effectively triple the number of functions you can program in a single profile. The default Keymap is Blue.

Mouse – Program n52te to emulate mouse clicks or scroll wheel functions. Polling Rate – Sets the polling rate to: 125Hz, 500Hz, or 1000Hz Note: You need to reduce the polling rate if your computer does not support USB 2.0.

Razer Synapse™ – Store one of your profiles in the onboard memory to take it with you! The profile stored with Razer Synapse will be available on any PC even without the software installed.

Main Screen of the n52te Editor

This figure shows the n52te Editor screen for the Nostromo n52 Tournament Edition.



The main screen consists of:

View of the Device - This makes clear which keys you are programming.

Macro Editor – This pane allows you to define and edit sequences of keyboard keystrokes, and/or mouse-button presses to create your own custom macros.

Profile Selection – This pane allows you to select which profile the n52te is currently using.

Help - This pane displays the Help menu for the n52te Editor.

CREATING A PROFILE

A profile is a set of remapped button and/or programmable functions for a specific application that can be saved and recalled at a later time.

This section will explain how to create a profile using the n52te Editor. In general, creating a profile consists of remapping button functions for the three Keymaps, configuring Auto-Switching options, then naming and saving your profile.

Remapping Single-Key Assignments

- 1. For the corresponding n52te button you wish to program, left click on it to bring up the context menu.
- 2. Select "Single Key" from the context menu. This will bring up the "Single Key" assignment dialog box. This screen is used to select a single key to assign to the selected n52te button. When a single key is assigned to a button, pushing the button is the same as pressing that key on the keyboard.
- At this point, press a key on the keyboard. The screen will display the name of the key you pressed.
- 4. Now you can click "OK" if you are happy with the current assignment, or you can click "Cancel" to abort the key assignment.

Macro Editor

Macros are recorded sequences of keyboard keystrokes, and/or mousebutton presses that can be saved played back by the n52te at a later time.

The Macro Editor pane is used to create, edit, and save macros. Saved macros can then be assigned to any button in any of the three Keymaps, and are available for use in any profile.



Current Macro Assignment – A list of keystrokes, delays, and other functions that are played back when the macro is executed. As you record a macro, the keyboard keystrokes that you type along with the actual time delays between the events will be listed in the "Current Macro Assignment" window.

Note: You cannot record mouse click commands and advanced functions during the recording phase, but you can add them manually from the "Advanced Functions" window.

Record - Starts macro recording.

Stop - Stops macro recording.

Move Up – Used to move an event up in the "Current Macro Assignment" sequence by selecting the event you want to move with your mouse and left-clicking on "Move Up" until it is in the desired position.

Move Down – Used to move an event down in the "Current Macro Assignment" sequence by selecting the event you want to move with your mouse and left-clicking on "Move Down" until it is in the desired position.

Select All – Selects all events in the "Current Macro Assignment" sequence list.

Select All Delays – Selects only the time delays in the "Current Macro Assignment" sequence list. This is helpful if you want to assign all delays the same value or eliminate them all at once.

Insert Delay – Allows you to manually insert a time delay in the "Current Macro Assignment" sequence list. Simply select an event then choose the desired duration and click on the "Insert Delay" button.

Ignore Delays Between Events – Turns playback of delays during the macro's execution On or Off. The macro's events will then play back at the maximum possible rate, which is approximately 10 milliseconds between events. This feature is Off by default.

Advanced – Reveals a list of advanced functions that can be inserted into the "Current Macro Assignment" sequence list.



Advanced functions that can be inserted into the "Current Macro Assignment" sequence list from this window include:

Basic Commands – Allows you to insert operations from a list of basic commands supported in Windows® OS.

Additional Commands – Allows you to insert operations from a list of additional commands supported in Windows® OS.

Media Functions – Allows you to insert operations for the default media player using a list of media commands.

Macro – Allows you to insert existing macros into the current one, thus creating a complex nested macro.

Mouse Button – Allows you to insert mouse-button clicks into the "Current Macro Assignment" sequence list by clicking the corresponding mouse button in the mouse figure.

MACRO BEHAVIOR

These three settings determine how the macro will be played back when triggered.

1. Run Times: X

This determines how many times the macro will be fully executed when the triggered. This setting defaults to a value of 1, meaning that the macro will be executed once.

2. Repeat while pressed.

Using this setting will force the macro to repeat continuously while the assigned button is held.

3. Repeat until next key is pressed.

Using this setting forces the macro-assigned button to act like a toggle switch. If you push it once and let go, the macro will continuously repeat until another key is pressed.

CREATING AND ASSIGNING A MACRO

- 1. Open "Macro Editor" pane by left-clicking on the arrow on the tab.
- 2. Left-click on the "Record" button to start recording keyboard events.
- 3. Using the keyboard, type in the key-press combination of the macro you want to create. This will normally be linking spells to create a new combo, or phrases, such as "cover me" you would send to your teammate. Notice the keys you press and release are recorded in the "Current Macro Assignment" sequence list.
- 4. Left-click on the "Stop" button to stop macro recording.
- 5. Click "Save" to save your newly created macro.
- Optionally, You can click on the "Advanced" button to display a list of Advanced Options, which you can insert into the macro.
- 7. If you are done editing your macro, return to the main n52te Editor screen.
- 8. Left-click on a desired button to open it's context menu.
- 9. You will see your new macro listed in the menu, left-click on it to assign it.

KEYMAPS

The n52te Editor allows you to program three Keymaps: Blue, Red, and Green. A Keymap allows you to add another layer of programming to each button. In order to switch between Keymaps during play, you must either dedicate a button for switching to the desired Keymap, or dedicate one to cycle through all three Keymaps. Because the second option of cycling through Keymaps requires only one button, two extra buttons are free for further customization.

Note: Buttons that are selected for one of these Keymap switching options will be dedicated to this function across all three Keymaps in the current profile.

- To program a Keymap switching function to a button, left-click on the desired button and select Blue, Red, or Green, or "Cycle Keymaps". For Blue, Red, and Green, you can select either "Momentary" or "Toggle".
- If you select "Momentary", the n52te will only load the desired keymap while you hold that button down. If you select "Toggle", the button acts like a switch and n52te will remain in the desired keymap until another keymap is selected.
- You can view and edit different Keymaps by clicking on Blue, Red, or Green labels above the device view graphic located at the main n52te Editor screen.
- · Please make sure to save your work.

PROFILE MANAGEMENT

You can manage profiles by using the following buttons on the main Editor Window.

New – Creates a new profile with default name "Untitled Profile 0x". Thereafter, you can specify a name for the profile.

Save - Saves all changes to the current profile.

Save As – Saves all changes to the current profile under a user-defined filename.

Import – Allows you to import a shared or downloaded profile into the n52te Editor and default profile folder.

Apply Changes – Activates recent changes made with the n52te Editor. This is different than saving in that the changes are made useable, but your profile is not overwritten. This is useful for testing out new programmable functions or macros without permanently changing your profiles.

Reset Keymap – Resets all key assignments in the current Keymap to their default settings. Note that they are not active until saving or pressing the "Apply Changes" button.

Profile Selection and Razer Synapse™

The "Profile Selection" pane displays the entire library of custom profiles located on your PC.



To change the currently active profile, click the "Profile Selection" tab to open the pane and choose the desired profile from the list.

Linked Application – Allows you to select an executable file for Auto-Switching. To do so, single left-click on the area and browse to a desired executable file or shortcut. To finish, single left-click the direction arrow to close the pane and click either "Save" or "Apply Changes" buttons.

Auto-Switching – Allows you to enable or disable profile Auto-Switching when the linked application is launched. To enable or disable, click the Auto-Switching check box next to the desired profile. An "x" indicates that Auto-Switching is enabled.

Note: In order for Auto-Switching to function, the profile must already be linked to an application executable.

The n52te is powered by Razer Synapse. This allows you to save one of your profiles to the n52te's onboard memory and use it on another PC, even without installing the n52te Editor software.

To load a profile to the n52te' onboard memory powered by Razer Synapse, open the Profile Selection pane and double click on the desired profile. The profile will be loaded when the Synapse icon appears next to the name. Now you can take your custom n52te settings with you anywhere.

HELP

If you have any problems using the n52te, simply click the "Help" tab to access the help file for any troubleshooting.

To update the n52te Editor software, simply click on the "Update" button to download the latest version of the software.



Using the n52te as a Default HID Device

If you choose not to install the software or create custom profiles, then by default your n52te will utilize the following functions:

- 1. Tab
- 2. Q
- 3. W
- 4. E 5. R
- 6. CAPS
- 7. A
- 8. S
- 9. D
- 10. F
- 11. SHIFT
- 12. Z
- 13. X
- 14. C
- 15. SPACE BAR

D-pad directions emulates the keyboard's arrow keys

Thumb pad emulates the "Space" key

Thumb button emulates the "ALT" key

The scroll wheel emulates a standard mouse scroll wheel with a third click

This default configuration works well with the default keyboard setup of most first-person shooter games

ADJUSTMENTS

Thumb-stick

The n52te comes equipped with a removable thumb-stick for customized control of the 8-way DPad. Simply pull the thumb-stick up away from the DPad to remove it if preferred.

Palm Rest Adjustment

The n52te is designed to adapt to hands of different sizes. There are three different hand-size adjustments that can be made to the palm rest in order to help you easily reach all of the n52te's buttons and keys.

- 1. For average-sized hands, no adjustment is necessary. The n52te's palm rest comes configured for the average-sized hand.
- 2. For large hands, you can easily increase the distance between the palm rest and the main keys. Simply pull the palm rest straight up away from the n52te's main chassis until it pops free. On the chassis you will see two sets of holes. Then reinsert the palm rest into the holes farthest from the main keys and snap it down firmly.
- For small hands, you can simply remove the palm rest completely for easier access to the n52te's array of buttons and keys.



INFORMATION

FCC Statement DECLARATION OF CONFORMITY WITH FCC RULES FOR ELECTROMAGNETIC COMPATIBILITY

We, Belkin International, Inc., of 501 West Walnut Street, Compton, CA 90220, declare under our sole responsibility that the product: F8GFPC200

to which this declaration relates:

Complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment may only be operated indoors. Operation outdoors is in violation of 47 U.S.C. 301 and could subject the operator to serious legal penalties.

CE Declaration of Conformity

We, Belkin International, Inc., declare under our sole responsibility that the F8GFPC200, to which this declaration relates, is in conformity with Generic Emissions Standard EN55022:1998 Class B, EN50081-1, and with Generic Immunity Standard EN50082-1:1992.

Belkin International, Inc., Limited Lifetime Product Warranty

What this warranty covers.

Belkin International, Inc. ("Belkin") warrants to the original purchaser of this Belkin product that the product shall be free of defects in design, assembly, material, or workmanship.

What the period of coverage is.

Belkin warrants the Belkin product for the lifetime of the product.

What will we do to correct problems?

Product Warranty.

Belkin will repair or replace, at its option, any defective product free of charge (except for shipping charges for the product).

What is not covered by this warranty?

All above warranties are null and void if the Belkin product is not provided to Belkin for inspection upon Belkin's request at the sole expense of the purchaser, or if Belkin determines that the Belkin product has been improperly installed, altered in any way, or tampered with. The Belkin Product Warranty does not protect against acts of God such as flood, lightning, earthquake, war, vandalism, theft, normal-use wear and tear, erosion, depletion, obsolescence, abuse, damage due to low voltage disturbances (i.e. brownouts or sags), non-authorized program, or system equipment modification or alteration.

How to get service.

To get service for your Belkin product you must take the following steps:

- Contact Belkin International, Inc., at 501 W. Walnut St., Compton CA 90220, Attn: Customer Service, or call (800)-223-5546, within 15 days of the Occurrence. Be prepared to provide the following information:
- a. The part number of the Belkin product.
- b. Where you purchased the product.
- c. When you purchased the product.
- d. Copy of original receipt.
- 2. Your Belkin Customer Service Representative will then instruct you on how to forward your receipt and Belkin product and how to proceed with your claim.

Belkin reserves the right to review the damaged Belkin product. All costs of shipping the Belkin product to Belkin for inspection shall be borne solely by the purchaser. If Belkin determines, in its sole discretion, that it is impractical to ship the damaged equipment to Belkin, Belkin may designate, in its sole discretion, an equipment repair facility to inspect and estimate the cost to repair such equipment. The cost, if any, of shipping the equipment to and from such repair facility and of such estimate shall be borne solely by the purchaser. Damaged equipment must remain available for inspection until the claim is finalized. Whenever claims are settled, Belkin reserves the right to be subrogated under any existing insurance policies the purchaser may have.

How state law relates to the warranty.

THIS WARRANTY CONTAINS THE SOLE WARRANTY OF BELKIN. THERE ARE NO OTHER WARRANTIES, EXPRESSED OR, EXCEPT AS REQUIRED BY LAW, IMPLIED, INCLUDING THE IMPLIED WARRANTY OR CONDITION OF QUALITY, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND SUCH IMPLIED WARRANTIES, IF ANY, ARE LIMITED IN DURATION TO THE TERM OF THIS WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL BELKIN BE LIABLE FOR INCIDENTAL, SPECIAL, DIRECT, INDIRECT, CONSEQUENTIAL OR MULTIPLE DAMAGES SUCH AS, BUT NOT LIMITED TO, LOST BUSINESS OR PROFITS ARISING OUT OF THE SALE OR USE OF ANY BELKIN PRODUCT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This warranty gives you specific legal rights, and you may also have other rights, which may vary from state to state. Some states do not allow the exclusion or limitation of incidental, consequential, or other damages, so the above limitations may not apply to you.

Free Tech Support*

You can find additional support information on our website www.belkin.com through the techsupport area. If you want to contact technical support by phone, please call the number you need from the list below*.

*Local rates apply

Country	Number	Internet adress	
AUSTRIA	08 - 20 20 07 66	http://www.belkin.com/uk	
BELGIUM	07 07 00 073	http://www.belkin.com/nl	
CZECH REPUBLIC	23 900 04 06	http://www.belkin.com/uk	
DENMARK	701 22 403	http://www.belkin.com/uk	
FINLAND	00800 - 22 35 54 60	http://www.belkin.com/uk	
FRANCE	08 - 25 54 00 26	http://www.belkin.com/fr	
GERMANY	0180 - 500 57 09	http://www.belkin.com/de	
GREECE	00800 - 44 14 23 90	http://www.belkin.com/uk	
HUNGARY	06 - 17 77 49 06	http://www.belkin.com/uk	
ICELAND	800 8534	http://www.belkin.com/uk	
IRELAND	0818 55 50 06	http://www.belkin.com/uk	
ITALY	02 - 69 43 02 51	http://www.belkin.com/it/support/tech	
LUXEMBOURG	34 20 80 8560	http://www.belkin.com/uk	
NETHERLANDS	0900 - 040 07 90 €0.10 per minute	http://www.belkin.com/nl	
NORWAY	815 00 287	http://www.belkin.com/uk	
POLAND	00800 - 441 17 37	http://www.belkin.com/uk	
PORTUGAL	707 200 676	http://www.belkin.com/uk	
RUSSIA	495 580 9541	http://www.belkin.com/uk	
SOUTH AFRICA	0800 - 99 15 21	http://www.belkin.com/uk	
SPAIN	902 - 02 43 66	http://www.belkin.com/es/support/tech	
SWEDEN	07 - 71 40 04 53	http://www.belkin.com/se/support/tech	
SWITZERLAND	08 - 48 00 02 19	http://www.belkin.com/uk	
UNITED KINGDOM	0845 - 607 77 87	http://www.belkin.com/uk	
OTHER COUNTRIES	+44 - 1933 35 20 00		

BELKIN®

www.belkin.com

Belkin Tech Support

UK: 0845 607 77 87

Europe: www.belkin.com/support

Belkin Ltd.	Belkin B.V.	Belkin GmbH
Express Business Park	Boeing Avenue 333	Hanebergstrasse 2
Shipton Way, Rushden	1119 PH Schiphol-Rijk	80637 Munich
NN10 6GL, United Kingdom	Netherlands	Germany
+44 (0) 1933 35 2000	+31 (0) 20 654 73 00	+49 (0) 89 14 34 05 0
+44 (0) 1933 31 2000 fax	+31 (0) 20 654 73 49 fax	+49 (0) 89 14 34 05 100 fax

Belkin SAS **Relkin Iheria Belkin Sweden** 130 rue de Silly Avda, Cerro del Aquila 3 Knarrarnäsgatan 7 92100 Boulogne-Billancourt 28700 San Sebastián de los Reyes 164 40 Kista France Spain Sweden +33 (0) 1 41 03 14 40 +34 91 625 80 00 +46 (0) 8 5229 1870 +33 (0) 1 41 31 01 72 fax +34 902 02 00 34 fax +46 (0) 8 5229 1874 fax

© 2007 Belkin International, Inc. All rights reserved. All trade names are registered trademarks of respective manufacturers listed. Windows is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.

P75561ea F8GFPC200ea